



••• ROLAND R-26 SMART GUIDE •••

QUICK SETUP

- put in batteries + SD card
- power up recorder
- press MENU

use the touch screen buttons controls to select and set menu items

1. FACTORY RESET
 - Sets input to internal mics
 - Sample rate = 44.1 kHz
 - Rec Format = WAV 16 bit
2. DATE/ TME - set
3. SD card - format
4. REC SETUP - optional
 - 2 channel
 - Rec source: internal
 - sample rate: 48.0 kHz
 - Rec Format: WAV 24 bit

RECORDING (wear headphones)

- press the MON tab to turn on headphone jack
- Press the REC button to go into pause
- adjust the input levels while the red light flashes
- ideal levels are between 12dB and -6dB
- press the SENS button to increase mic pickup
- press REC to start recording

Start audio recording before video recording and stop audio recording after stopping video recording.

NO BATTERIES ? -
Use the AC adapter and plug it into a wall outlet.

CLOSE X

- Press Menu twice to quit

Front panel

Rear panel

Left side panel

Right side panel

Top

Bottom



- | | |
|--------------------------|-------------------------------|
| 1 Touch panel display | 9 PLUG IN MIC jack |
| 2 INPUT LEVEL knobs | 10 Preview Monitor |
| 3 Battery compartment | 11 PHONES jack |
| 4 Tripod mounting socket | 12 VOLUME dial |
| 5 SD card slot | 13 Omnidirectional (OMNI) mic |
| 6 USB connector | 14 Directional (XY) mic |
| 7 POWER/HOLD switch | 15 XLR/TRS jack |
| 8 DC IN jack | |

Using external microphones

- 1.REC SETUP
 - 2 channel
 - Rec source: Analog Mono: 2 mics
 - Analog : 1 mic
- 2.INPUT SETUP
 - Analog in: separate or link